
TABLE OF CONTENTS

GENERAL	2
PREPARATION	3
Project Definition	3
Pre-installation visit & checklist	4
Network	5
Cabling Diagram	7
INSTALLATION	9
Cabling	10
Pass Gateway rack Placement	11
displays Placement	12
camera Placement	14
CONNECTING	17
Connecting Rack	17
Connection to legacy PMS & barriers	18
Connection Barriers	19
Loops	20
POWER-UP & CONFIGURATION	21
Acceptance Installation	21
Acceptance Cabling & External Connections	22
Rack	23
I/O Module	24
Network Access	27
PC	28
Network Switch	29
UPS	32
Keypad	35
Camera's Survision	36
Displays	38
ERROR SCENARIO'S	45

ACCEPTANCE CABLING & EXTERNAL CONNECTIONS

Scenario:

start conditions:

- UPS OFF
- Mains automatic fuse OFF
- mains power connected to displays (Singage screens)
- Mains automatic fuse ON
- Check power of displays (Singage screens)
- power up UPS
- check if network equipment has started
- check power supplies (+24V) adjust voltage level if needed
- check voltage and polarity on the power connectors at the camera side.
- connect power to the camera
- connect network cable to camera.
- connect pc to the camera network plug in the patch panel.

.... gaan we zo alle stappen oplijsten?? dat gaat een lange lijst worden met verschillende items voor bvb cameras, displays, pinpads, rack etc