
TABLE OF CONTENTS

GENERAL	2
PREPARATION	3
Project Definition	3
Pre-installation visit & checklist	4
Network	5
Cabling Diagram	7
INSTALLATION	9
Cabling	10
Pass Gateway rack Placement	11
displays Placement	12
camera Placement	14
CONNECTING	17
Connecting Rack	17
Connection to legacy PMS & barriers	18
Connection Barriers	19
Loops	20
POWER-UP & CONFIGURATION	21
Acceptance Installation	21
Acceptance Cabling & External Connections	22
Rack	23
I/O Module	24
Network Access	27
PC	28
Network Switch	29
UPS	32
Keypad	35
Camera's Survision	36
Displays	38
ERROR SCENARIO'S	45

I/O MODULE

Configuration

	64 inputs
EK6420 module	20 outputs
Network: IP address, WEB port, TCP Binary port,	
Redundant config: basic and redundant setup	Rack IO

I/O Connection Table

No	Rack IO		
0	UPS	On Battery	RACK INFO
1	UPS	Low Battery	RACK INFO
2	Power Supply 1	Ready	RACK INFO
3	Power Supply 2	Ready	RACK INFO
4	Network switch	Fault	RACK INFO
5	Network switch	Fault	RACK INFO
6	RED module 1	Status	RACK INFO
7	RED module 2	Status	RACK INFO
8	RED module 3	Status	RACK INFO
9	RED module 4	Status	RACK INFO
10	RED module 5	Status	RACK INFO
11	RED module 6	Status	RACK INFO
12			
13			
14	Camera fuse 1	Power supply behind fuse	RACK INFO
15	Camera fuse 2	Power supply behind fuse	RACK INFO
16	Camera fuse 3	Power supply behind fuse	RACK INFO
17	Camera fuse 4	Power supply behind fuse	RACK INFO
18			
19			
20			
21			
22			
23			
24			

Entry terminal IO

No	Entry	
1	Loop Terminal	Status loop detector
2	Loop Barreer	Status loop detector