TABLE OF CONTENTS

GENERAL 2

PREPARATION 3
I Project Definition 3
I Pre-installation visit & checklist 4
I Network 5
I Cabling Diagram 7

INSTALLATION 9
I Cabling 10
I Pass Gateway rack Placement 11
I displays Placement 12
I camera Placement 14

CONNECTING 17
I Connecting Rack 17
I Connection to legacy PMS & barriers 18
I Connection Barriers 19
I Loops 20

POWER-UP & CONFIGURATION 21
I Acceptance Installation 21
I Acceptance Cabling & External Connections 22
I Rack 23
I I/O Module 24
I Network Access 27
I PC 28
I Network Switch 29
I UPS 32
I Keypad 35
I Camera's Survision 36
I Displays 38

ERROR SCENARIO'S 45

NETWORK SWITCH

MACH-102

MACH 102-24TP-F

Industrial ETHERNET (Gigabit) Switch.



RED 25

This module is only used in the redundant rack configuration and is needed to split single ended network users into two Ethernet access connections running PRP (Parallel Redundant Protocol)