

TABLE OF CONTENTS

GENERAL	2
PREPARATION	3
Project Definition	3
Pre-installation visit & checklist	4
Network	5
Cabling Diagram	7
INSTALLATION	9
Cabling	10
Pass Gateway rack Placement	11
displays Placement	12
camera Placement	14
CONNECTING	17
Connecting Rack	17
Connection to legacy PMS & barriers	18
Connection Barriers	19
Loops	20
POWER-UP & CONFIGURATION	21
Acceptance Installation	21
Acceptance Cabling & External Connections	22
Rack	23
I/O Module	24
Network Access	27
PC	28
Network Switch	29
UPS	32
Keypad	35
Camera's Survision	36
Displays	38
ERROR SCENARIO'S	45

CONNECTING

CONNECTING RACK

To Mains Power

The mains power of the rack should be connected to a power outlet supplying (2200W? / 10A)

(to be reviewed)

To Camera's

The power cables from the cameras will be connected to the DIN terminals in the rack. They are connected via an individual fuse to the 24V supply rail.

To Network

A network cable will arrived at a terminal of the patch panel in the rack. There it will be connected to a network switch (in a Basic configuration connected to the network switch or in a Redundant configuration to a Red module)

To Displays

The mains power of the displays are connected to DIN rail terminals. These are connected to the fused mains power input. (The displays are not connected to the UPS)